

Description of Sweep Process

- 1) Visual inspection of chimney inside house and outside as well
- 2) Look for safe place to set up ladder
- 3) Set up black 8x8 tarp in front of the fireplace
- 4) Set up soot-free vacuum system in front of firebox (The entire process is 100% soot-free).
- 5) Close all windows and doors to create a 0% air pressure in house
- 6) Turn vacuum on
- 7) Go on roof. We use a 12x10 metal brush in an up & down motion connected to 6 foot fiberglass poles to sweep the flue liner.
- 8) Go back into the house. The firebox is now completely brushed and all soot collected into the vacuum system.
- 9) After sweep is done we do a final inspection to make sure nothing is missed.
- 10) All equipment is then moved out and work area checked for cleanliness.

Video Scan

We use state of the art high definition cameras and ipads to video scan the flue and smoke chamber. In this way we can accurately determine if there are any cracked liners or breeches in the interior of the chimney. Customers are encouraged to watch the screen as the camera goes up the chimney. All images are in high definition.